



3M Hygiene kit for Peltor X4

Produktnummer: 3MHYX4

- Specially modified with a probe tube for fit testing 3M™ PELTOR™ Optime™ Earmuffs
- For use with 3M™ E-A-Rfit™ Validation System to measure HPE effectiveness
- Should not be used as hearing protection
- Suitable for multiple uses and can be cleaned with hygiene wipes
- Easily click into X Series Earmuffs to test effective wear of protection



3M™ PELTOR™ X Series Earmuffs Probed Test Cushions are especially designed with a probe tube to enable individual worker fit testing for 3M PELTOR Earmuff X-Series. The one set of cushions works to test both X4 and X5 models.

3M™ PELTOR™ Earmuffs Probed Test Cushions work with the X4 and X5 earmuffs (sold separately) to allow for fit testing with the 3M™ E A Rfit™ Dual Ear Validation System. These cushions are used specifically with the 3M PELTOR X Series X4 and X5 Earmuffs to help employers determine the level of protection the earmuffs are providing. Adapter clips hold microphones next to earmuffs for proper positioning during testing. Case includes two pair of probed cushions and two pair of adapter clips. Workers can bring the 3M PELTOR X Series Earmuffs they are using in the workplace, have the operator remove and inspect their cushions, replace them with the appropriate probed test cushions, and be fit tested.



Les mer om produktet her:

<https://www.redwingnordic.com/product?number=3MHYX4>